



ConDePhase® Plus Sizing Graphs

SIZING INSTRUCTIONS

To size the Super Capacity ConDePhase® Plus unit for your particular application, first select the correct chart for the ISO viscosity grade of the lubricant being used in the air compressor. **1.** Locate the compressor capacity on the vertical scale at the left hand side of the graph. **2.** From this point travel horizontally to the right until you intersect the line representing the base stock of the lubricant being used in the compressor. **3.** At this intersection, travel vertically downward to the bottom scale indicating the recommended unit size. **NOTE:** If you arrive at a point on the scale that indicates the maximum capability of the unit...it is advised to recommend the next larger size unit. Example below indicates a ConDePhase® Plus 400 is needed.



ISO 32 & 46 LUBRICANTS




ISO 32 & 46 LUBRICANTS

ConDePhase® Plus Sizing Graphs

■ Polyglycol ■ Petroleum ■ Diester ■ PAO

Standard Models


Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE

Super Capacity Models

Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE


ISO 68 LUBRICANTS

ConDePhase® Plus Sizing Graphs

■ Polyglycol ■ Petroleum ■ Diester ■ PAO

Standard Models


Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE

Super Capacity Models

Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE


ISO 100+ LUBRICANTS

ConDePhase® Plus Sizing Graphs

■ Polyglycol
 ■ Petroleum
 ■ Diester
 ■ PAO

Standard Models


Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE

Super Capacity Models

Compressor Capacity, SCFM



ConDePhase® Plus UNIT SIZE